



## 14297-RF

**Item Number 4677817**

Mechanical expander tool set with 6 heads (3/8" to 1 1/8") for expanding soft copper pipe

### Accessories

4669750	14297-RF-1"	Spare head ø 1"
4687345	HY-EX-1"	Spare head ø 1"
4669776	14297-RF-1 3/8"- 35MM	Spare head ø 1 3/8"
4687347	HY-EX-1 3/8"	Spare head ø 1 3/8"
4669785	14297-RF-1 5/8"	Spare head ø 1 5/8"
4687348	HY-EX-1 5/8"	Spare head ø 1 5/8"

### Spare Parts

4669709	14297-RF-3/8"	Spare head ø 3/8"
4669717	14297-RF-1/2"	Spare head ø 1/2"
4669726	14297-RF-5/8"	Spare head ø 5/8"
4669734	14297-RF-3/4"	Spare head ø 3/4"
4669742	14297-RF-7/8"	Spare head ø 7/8"
4669768	14297-RF-1 1/8"	Spare head ø 1 1/8"
4687344	HY-EX-1/4"	Spare head ø 1/4"
4687367	HY-EX-3/8"	Spare head ø 3/8"
4687346	HY-EX-5/16"	Spare head ø 5/16"
4687366	HY-EX-1/2"	Spare head ø 1/2"

*Acknowledged globally*



4687365	HY-EX-5/8"	Spare head ø 5/8"
4687368	HY-EX-3/4"	Spare head ø 3/4"
4687369	HY-EX-7/8"	Spare head ø 7/8"
4687370	HY-EX-1 1/8"	Spare head ø 1 1/8"
4687579	HY-OIL	Hydraulic oil for HY-EX, 50ml
4687384	HY-EX-V	Spare latch for HY-EX case